

Ship To:



527 Park Lane #200

Waterloo, Iowa 50702

1-800-408-3598

Fax 1-800-408-3595

E-mail info@oandp1.com

CROW Walker Work Order

Patients Name: _____ Left Right

Practitioner _____ Date Measured _____

Phone Number _____ Date Needed _____

P.O. _____

Crow Walker

- Crow Walker W/ Liner
- Add PTB Features

Cast Corrections

- Leave as casted
- Correct to 90 degrees

Posterior Plastic

- Polypro: 3/16" 1/4"
- Color _____
- Copoly: 3/16" 1/4"
- Color _____

Anterior Plastic

- Polypro: 1/8" 3/16"
- Color _____
- Copoly: 1/8" 3/16"
- Color _____

Liner

- Pink Plastazote 1/4"
- Aliplast 1/8" 3/16" 1/2"

Insole Material

- Pink Plastazote 1/4" 1/2"
- 1/8" PPT / 1/4" Plastazote

Straps

- 1 1/2"
- 2"
- Dacron Reinforced Strap
- Color: Black or White

Special Instructions:

Casting

Casting a patients foot at an angle of 90 degrees or as close to that position as possible is imperative for proper modification in the construction of the CROW Walker, as importantly, is the casting of the knee to the relationship of the foot.

- A. Place plaster strips over the distal end of the toes. A clear reference by means of plaster strips will give us the exact starting point for the toe build up and modifications.
- B. Mark bony prominences and potential problem areas.
- C. Wrap Leg using standard procedure for casting.

Measurements

All Measurements must be taken. The foot measurements should be taken partially weight bearing with the toes fully extended, Add 1/2 to 3/4 inch to the patients full foot measurement for the finished length.

Heel to Toe Rocker Sole (O&P1 Standard)

